

PS-1230



MDB-E3110



NC
COM
NO

Button
GND

+ -

+ - NC COM NO

AX-M620



AX-TOUCH1

