



Explosión TC320			
No.	Model	DESCRIPCION	Material No.
1	TC320	CUBIERTA DE CANAL 6201658001010	6201658001010
2	TC320	TORNILLO PARA CUBIERTA DE CANAL	7102006000100
3	TC320	PERILLA DE CANAL 6000718100000	6000718100000
4	TC320	TUERCA PARA FIJACION 7206007400000	7206007400000
5	TC320	ANILLO PARA ANTENA 6100335000000	6100335000000
6	TC320	GUIA DE LUZ PARA LED 6000737100010	6000737100010
7	TC320	GUIA DE LUZ P/INDICADOR DE SEÑAL	6000736100000
8	TC320	BOTON ON-OFF 6100363000010	6100363000010
9	TC320	MALLA METALICA DE ALTA VOZ 6201644000000	6201644000000
10	TC320	LAMINA DE TELA 7400229000000	7400229000000
11	TC320	EMPAQUE DE ALTA VOZ 7500250000000	7500250000000
12	TC320	CABLE DE SEÑAL 4210038000000	4210038000000
13	TC320	CUBIERTA DE AURICULAR 6000739000030	6000739000030
14	TC320	PIEZA PARA DESCARGA DE BATERIA 6201643000000	6201643000000
15	TC320	TAPA POSTERIOR 6002039000000	6002039000000
17 & 24 & 26 & 26	TC320	KIT CUBIERTA BATERIA 1520032000400	1520032000400
27	TC320	TORNILLO DE TAPA POSTERIOR 7102008020100	7102008020100
28	TC320	HOJA DE BLINDAJE 7600036000000	7600036000000
29	TC320	HOJA PARA PCB 7400233000000	7400233000000
30	TC320	AISLANTE DE ALTA VOZ 7400034000000	7400034000000
31	TC320	ALTA VOZ 5001000000090	5001000000090
32	TC320	TORNILLO 7101903220000	7101903220000
33	TC320	ELECTRODO DE CARGA 6201671000000	6201671000000
34	TC320	ANILLO DE SOPORTE 7209802800010	7209802800010
35	TC320	SELECTOR DE CANAL 4304030000030	4304030000030
36	TC320	SOPORTE DE ANTENA 6201653000020	6201653000020
37	TC320	TORNILLO 7101704020100	7101704020100
38	TC320	SWITCH 4301040000060	4301040000060
39	TC320	ESPONJA CONDUCTORA 7600037000000	7600037000000
40	TC320	HOJA DE COBRE 7600020000000	7600020000000
41	TC320	RADIO (H)12000320U0090	12000320U0090
	TC320	RADIO U(1) 1200320410020	1200320410020
	TC320	RADIO UHF 12000320U0010	12000320U0010
42	TC320	MICROFONO 5002230000010	5002230000010
43	TC320	GOMA DE SILICA 6100111000010	6100111000010
44	TC320	MALLA 7400077000000	7400077000000
45	TC320	TAPA FRONTAL 1500032000000	1500032000000
46	TC320	PIEZA DECORATIVA DE ZINC 6300062001010	6300062001010
47	TC320	GOMA PTT 6100365000000	6100365000000
48	TC320	TECLA PTT 6000735000020	6000735000020



Electronic Parts on PCB Board			
50	TC320	SWITCH ON-OFF 4301080000020	4301080000020
51	TC320	AMPLIFICADOR OPERATIVO 3605008005070	3605008005070
52	TC320	AMPLIFICADOR DE AUDIO 3602012000020	3602012000020
53	TC320	REGULADOR DE VOLTAJE 3615042000010	3615042000010
54	TC320	SWITCH DE VOLUMEN 4301080000090	4301030000090
55	TC320	REGULADOR DE VOLTAJE 3609049000010	3609049000010
56	TC320	SCM SRT3210 3610999000060	3610999000060
57	TC320	CRISTAL 3701327610060	3701327610060
58	TC320	MEMORIA 16KB 3612031000510	3612031000510
59	TC320	DEMODULADOR 3920450300000	3920450300000
60	TC320	FILTRO CERAMICO 3801045030390	3801045030390
61	TC320	CRISTAL RX 3802021750090	3802021750090
62	TC320	FILTRO 3803041560000	3803041560000
63	TC320	FMIF IC 3603042004860	3603042004860
64	TC320	TCXO DSAS35S C 3701212540030	3701212540030
65	TC320	PLL MB15E03SL-E1 3604007000000	3604007000000
66	TC320	TRANSISTOR NPN 3408002000030	3408002000030
67	TC320	PUERTO MINI USB 5205005000100	5205005000100
68	TC320	N-MOSFET 3502010000130	3502010000130
69	TC320	POWER MOSFET 3504990000040	3504990000040
70	TC320	JACK PARA AURICULAR 5205006000010	5205006000010



